



SEAL SAFE INSTALLATION INSTRUCTIONS

FREIGHT DEFENSE

Toll Free: (920) 499-0022 · 1271 Contract Drive · Green Bay, WI 54304 · customerservice@freightdefense.com



CONTENT

1 Stainless Steel Seal Safe unit

TECH SUPPORT

Call toll free (855) 935-9999

TOOLS REQUIRED

Power drill and 1/4" pop rivets

PLEASE NOTE

The Seal Safe is designed for a padlock with a 7/16" shackle. Contact us for specific padlock recommendations.



While facing the trailer at the back of the truck, open the right door handle. With the Seal Safe cover raised, place the Seal Safe over the latching mechanism.



While the Seal Safe cover is still raised, close the door, lock handle, and flip the hasp into its closed position. Verify that the handle is properly seated and the Seal Safe is true and square.



Trace the outline of the Seal Safe and hole pattern (a pencil will work best). Remove Seal Safe. Drill the holes that were stenciled to accept the 1/4" rivets or fasteners.



Remove the Seal Safe and align with stencil marks.



Install the mechanical fasteners.

For the latest instructions and install video please visit www.freightdefense.com

SECURITY FOR THE LONG HAUL