



INSTALLATION INSTRUCTIONS

Model PL5500CONV
2005-2015 Toyota Tacoma
Valet Conversion Kit

Package Contents: Standard Lock, Nut, Bezel Clip
Lock Adapter, Cam, Pawl,
Screw and Washer, Instructions

Tools Required: Phillip and Flat Screwdriver Driver
7/8" and 1 1/4" Wrench

Process for removing standard lock from handle: This process is easier to do with the handle removed from the truck. Remove the latch rods from the plastic clips. Do this by turning the clips off of the rod and lift the rod out of the clip. If truck has a back up camera, remove the two 10mm bolts that hold the camera and holder onto the handle. Remove the two 10mm bolts that hold the handle into the tailgate. Hold the handle in place to prevent the handle from falling out. Push the two plastic tabs of the gasket in towards the handle past the sheet metal and remove the handle from the tailgate. Remove the lock cylinder (this is shown in pictures below).

Remove the phillip screw and the plastic pieces the screw goes through

Remove the nut from the lock cylinder and remove the lock

Remove the metal clip by sliding of the plastic lock adapter. Remove the plastic lock adapter by pushing it out of the bezel



Process for removing code-able lock from handle: This process is easier to do with the handle removed from the truck. Remove the latch rods from the plastic clips. Do this by turning the clips off of the rod and lift the rod out of the clip. If truck has a back up camera, remove the two 10mm bolts that hold the camera and holder onto the handle. Remove the two 10mm bolts that hold the handle into the tailgate. Hold the handle in place to prevent the handle from falling out. Push the two plastic tabs of the gasket in towards the handle past the sheet metal and remove the handle from the tailgate. Remove the lock cylinder (this is shown in pictures below).

Remove Phillip screw from back of lock cylinder and remove the screw washer and plastic cam

Remove the plastic lock housing by prying back on two tabs (shown by the arrows in the pictures below) and lifting the housing and spring off of the lock cylinder

Remove the nut around the lock cylinder and remove the cylinder from the handle assembly



Technical Support:
Call 1-800-342-5911

technicalsupport@popandlock.net

Installing the Standard Lock cylinder:

Install the lock adapter into the handle assembly by pushing it in. It can only go one way.



Install the bezel clip onto the lock adapter by sliding the clip through the grooves and into place. This may take a little force.



Install the lock cylinder through the lock adapter and install the nut and tighten.



Put together the cam and the pawl. They will slide together only one way.



Install the cam/pawl assembly onto the back of the lock. The triangular opening must go around the post and the square cut out must align with the back of the square on the back of the lock cylinder. Put the washer on the screw and insert screw into the hole at the top of the cam/pawl assembly. Tighten screw tight.



Step 5: - Test the function of the lock. Turn the key clockwise and back to center to lock. Turn the key counter clock wise and back to center to unlock



Step 6: If the lock operates properly, reinstall the handle into tailgate and reinstall the access panel.

LIMITED WARRANTY TERMS AND CONDITIONS

- (1) **Installation.** Pop & Lock™, LLC (and Pop & Lock™ Corporation) is not responsible for installing the Pop & Lock™ or for the harm suffered by any person as a result installing it.
- (2) **Warranties.**
- Customer acknowledges that it is unreasonable to believe that any device whatever will prevent a theft in the case of every attempt and that the most that can be expected from a so-called anti-theft or security device is that it will deter many thieves.
 - **POP & LOCK™ LLC. (and Pop & Lock™ Corporation) MAKES, AND CUSTOMER RECEIVES, NO WARRANTY, EXPRESSED OR IMPLIED, EXCEPT THE WARRANTIES OF TITLE TO THE POP & LOCK™ AND THEIR MERCHANTABILITY, PARTICULARLY NO WARRANTY OF FITNESS FOR A PARTICULAR USE OR PURPOSE OR AGAINST INFRINGEMENT.**
 - As Customer's only remedy, Pop & Lock™, LLC (and Pop & Lock™ Corporation) will repair or replace, at its option and without charge, any lock that is defective in material or workmanship when received by Customer and is returned to Pop & Lock™ LLC (and Pop & Lock™ Corporation), FOB Pop & Lock™ Corporation's offices, within one year after it's receipt by the Customer. Pop & Lock LLC will ship all replacement, or repaired, Locks to Customer, FOB Pop & Lock™'s shipping point.
 - Factory support is only available for Pop & Lock™ products purchased as **new** through an Authorized Pop & Lock™ dealer.
Please Note: Pop & Lock™ Products purchased on auctions sites such as Craigslist etc. will not be covered under factory warranty. Products purchased from an authorized dealer as "new" on websites such as Amazon and Ebay must follow their website warranty policy, process and procedures. Pop & Lock™ Products sold as "used", "refurbished", "open box" etc., cannot be verified by Pop & Lock™, LLC (and Pop & Lock™ Corporation), and as such, Pop & Lock, LLC (and Pop & Lock™ Corporation) is unable to warranty such purchases. Pop & Lock, LLC advises using extreme caution when buying through auction sites as you'll be doing so at your own risk.

No Liability. Pop & Lock™ Corporation is not liable for any loss or damage claimed by Customer or any third person to have been suffered or incurred as a result or, or related to, the Locks purchased under this Agreement, regardless of the circumstances or form of action, except any bodily injury or death for which Pop & Lock™ is liable under products-liability law. Without limiting the generality of the foregoing, in no event will Pop & Lock™ LLC be liable to Customer for any indirect, special, or consequential damages, regardless of the circumstances or the cause of action, particularly not for the value of a vehicle, or any other money damages in the event that a tailgate is stolen either notwithstanding the use of a Pop & Lock™ or when it has been returned for repair or replacement.

END OF TERMS AND CONDITIONS

POP & LOCK LLC 1271 CONTRACT DRIVE GREEN BAY, WI USA 54304

Additional Install Instructions and answers to technical questions can be found on our website at www.popandlock.net or by calling

Technical Support 1-800-342-5911 option 1

Monday – Friday 8:30am to 4:30pm CST

Pop and Lock's limited warranty expires one (1) year after date of purchase.

Proof of purchase is required for warranty claims. Please submit a scanned copy or electronic image/photo of your receipt through any of the following methods:

- E-mail: technicalsupport@popandlock.net
- Fax: 855-491-5911
- Mail: 1271 Contract Ave, Green Bay, Wisconsin (USA) 54304

Please be sure to include:

- Name, address and phone number
- Model and year of truck
- Model/Part number of the lock
- Brief description of the problem

